




Connector Replacement Parts

Conn. type	Single pin*	Five-pin* pack
L44CW	220040	
L44DF	Assembly**	
L44DM	46088	
L44EN	207983	
L44ER	43500	
L44EW	43265A-2	
L44F	44584	
L44J	44343	
L44M	44355	
L44N	45124	45124-5
L44NT	45549	
L44P	43311	
L44R	43500	
L44T	207264	
L44U	43337	
L44W	43265A	43265A-5
204516	45124	
206405	206445	
206406	206447	
209865	209864	
48923	43265A-4	

Single-connector gasket reattachment kit 34767A-27 contains gaskets, silicone grease, and spacing gauge

*Inner connector

**Assembly and finishing required



L44M
(LC male)



L44T
(End terminal)



L44DF
(DIN female)



L44DM
(DIN male)



L44NT
(TNC female)



L44J
(HN male)



L44F
(F flange male)
installed after
body installed



209865
(F flange female)



L44N/EN/204516
(N female)



L44EW/48923/206405
(N male)



L44R/ER/206406
(7/8" EIA flange)



L44U
(UHF female)




L44P
(UHF male)



L44CW
(SC male)

8 Assembly of screw terminal parts on L44T



Andrew Corporation
Orland Park, IL U.S.A. 60462
Andrew Antennas
Weybridge, Surrey, England
Andrew Canada Inc.
Whitby, Ontario Canada

Andrew Antennas
Campbellfield, Victoria, Australia
Andrew AG
Zurich, Switzerland

Antenas de Transmision S.A. de C. V.
Mexico, D.F. Mexico
Antennes Andrew S.A.R.L.
Buc, France

Andrew Corporation
Tokyo, Japan
Andrew S.R.L.
Milan, Italy
4/89
Printed in U.S.A.