



www.Source1Parts.com

HVAC SERVICE PARTS

ERHS SERIES - 13 SEER X3 HEAT PUMP (R22) (STYLE A)

Supersedes:035-20742-001 Rev. F (1207)

035-20742-001 Rev. G (0308)

1 of 4




FIG	ITEM	DESCRIPTION	ERHS0181BAA	ERHS0241BAA	ERHS0301BAA	ERHS0361BAA
1	1	Compressor	015-03814-000	015-03813-000	015-03811-000	015-03812-000
*	1A	Harness, Compressor	025-31884-000	025-31884-000	025-31884-000	025-31884-000
1	2	Motor, Fan	024-26029-000	024-27596-000	024-27596-000	024-27596-000
1	3	Capacitor, Run (30/5MFD) [RC]	024-24778-000	---	---	---
		Capacitor, Run (25/5MFD) [RC]	---	024-23997-000	---	---
		Capacitor, Run (35/5MFD) [RC]	---	---	024-23998-000	---
		Capacitor, Run (40/5MFD) [RC]	---	---	---	024-25893-000
1	4	Sensor, Temperature	025-32701-016	025-32701-016	025-32701-016	025-32701-016
1	5	Contact, Electrical (30 amp) [M]	024-27531-000	024-27531-000	024-27531-000	024-27531-000
1	6	Control, Defrost	031-01975-102	031-01975-102	031-01975-102	031-01975-102
*	7	Control, Pressure	025-33305-048	025-33305-048	025-33305-048	025-33305-048
1	8	Sensor, Liquid Replacement	031-01276-000	031-01276-000	031-01276-000	031-01276-000
1	9	Capacitor, Start	024-25062-000	024-25062-000	024-25071-000	---
1	10	Coil, Solenoid	025-38948-000	025-38948-000	025-38948-000	025-38948-000
*	11	Relay, Start	024-25916-000	024-25916-000	024-25391-000	---
1	12	Blade, Fan	026-39474-000	026-34593-000	026-34593-000	026-34593-000
1	13	Accumulator	026-34090-000	026-34089-000	026-34090-000	026-34090-000
1	14	Coil, Condenser	373-23787-001	373-23787-002	373-23787-003	373-23787004
1	15	Distributor (.040 Orifice)	022-09081-000	---	---	---
		Distributor (.050 Orifice)	---	---	022-09080-000	---
		Distributor Assembly	---	025-33424-233	---	025-33424-234
*	16	Switch Heater Limit	---	---	025-31924-000	---
1	17	Muffler	025-39847-000	025-39847-000	025-39847-000	---
*	18	Filter Drier	1458-0011	1458-0011	6536-3341	6536-3341
	19					
1	20	Valve, Reversing	025-38945-000	025-38945-000	025-38945-000	025-38945-000
1	21	Valve, Liquid (3/8")	025-31899-000	025-31899-000	025-31899-000	025-31899-000
1	22	Valve, Suction (3/4")	025-31900-000	025-31900-000	---	---
		Valve, Suction (7/8")	---	---	025-31901-000	025-31901-000
1	23	Wireway, (Electric Channel)	028-13216-001	028-13216-001	028-13216-001	028-13216-001
1	24	Cover, Electric Box	073-20018-001	073-20018-001	073-20018-001	073-20018-001
1	25	Base, Pan	073-20004-801	073-20004-801	073-20004-801	073-20004-801
1	26	Panel, Top	073-20042-801	073-20042-801	073-20042-801	073-20042-801
1	27	Plate, Block-Off	073-20002-801	073-23791-001	073-23791-002	073-20002-804
1	28	TXV (Sweat)	---	025-39911-000	---	022-09093-000
		TXV (Flare)	---	025-38907-000	---	---
*	29	Harness, Solenoid Coil	1456-9771	1456-9771	1456-9771	1456-9771
1	30	Ground Lug	025-21798-000	025-21798-000	025-21798-000	025-21798-000
1	31	Strain Relief	1216-243	1216-243	1216-243	1216-243
1	32	Guard, Coil (1 Req'd)	373-23707-001	373-23790-002	373-23790-007	373-23847-001
1	33	Guard, Fan	026-35511-822	026-35511-822	026-35511-822	026-35511-822
1	34	Isolator, Compressor (Pkg. of 4)	9435-1081	9435-1081	9435-1081	9435-1081
1	35	Plastic Mesh, Coil Guard	028-14728-000	028-15241-000	028-15240-000	028-14733-000
*	36	Fastener, Push-in (4 Req'd)	021-18381-000	021-18381-000	021-18381-000	021-18381-000
*	37	Diagram, Wiring	125830	125830	125830	125830
1	38	Kit, Motor Mounting (Acorn Nuts)	363-90117-700	363-90117-700	363-90117-700	363-90117-700
*	39	Check Valve w/Muffler	---	---	---	022-09077-000

NOTE: *Not ShownNew replacement parts shown in **bold** face type at the first printing of parts list dated 3/08.

Major components and suggested stocking items are shown with shaded item number.

"←" Across from row indicates a change in that row.

--- Not applicable to specified model.

Refer to Tech Guide for proper selection of orifice.



FIG	ITEM	DESCRIPTION	ERHS0421BAA	ERHS0481BAA	ERHS0601BAA
1	1	Compressor	015-03815-000	015-03657-004	015-03679-004
*	1A	Harness, Compressor	025-31884-000	025-31884-000	025-31884-000
1	2	Motor, Fan	024-27596-000	024-27596-000	024-27596-000
1	3	Capacitor, Run (45/5MFD) [RC]	024-25895-000	---	---
		Capacitor, Run (60/5MFD) [RC]	---	024-25033-000	---
		Capacitor, Run (70/5MFD) [RC]	---	---	024-27616-000
1	4	Sensor, Temperture	025-32701-016	025-32701-016	025-32701-016
1	5	Contactora, Electrical (30 amp) [M]	024-27531-000	024-27531-000	---
		Contactora, Electrical (40 amp) [M]	---	---	024-25837-000
1	6	Control, Defrost	031-01975-102	031-01975-102	031-01975-102
*	7	Control, Pressure	025-33305-048	025-33305-048	025-33305-048
1	8	Sensor, Liquid Replacement	031-01276-000	031-01276-000	031-01276-000
1	9	Capacitor, Start	---	---	---
1	10	Coil, Solenoid	025-38948-000	025-38948-000	025-38948-000
*	11	Fan Relay	---	---	---
1	12	Blade, Fan	026-34593-000	026-42195-000	026-42195-000
1	13	Accumulator	026-34090-000	026-25573-008	026-25573-008
1	14	Coil, Condenser	373-23787-007	373-23787-005	373-23787-006
1	15	Distributor Assembly	025-33424-238	025-33424-238	025-33424-238
*	16	Switch Heater Limit	---	---	---
1	17	Muffler	---	---	---
*	18	Filter Drier	6536-3341	026-34506-000	026-34506-000
	19	Corner Post			
1	20	Valve, Reversing	025-38947-000	025-38947-000	025-38947-000
1	21	Valve, Liquid (3/8")	025-31899-000	025-31899-000	025-31899-000
1	22	Valve, Suction (7/8")	025-31901-000	025-31901-000	025-31901-000
1	23	Wireway, (Electric Channel)	028-13216-001	028-13297-000	028-13297-000
1	24	Cover, Electric Box	073-20018-001	073-20018-001	073-20018-001
1	25	Base, Pan	073-20004-801	073-19001-500	073-19001-500
1	26	Panel, Top	073-20042-801	073-23757-001	073-23757-001
1	27	Plate, Block-Off	073-20002-804	073-23791-002	073-20002-804
1	28	TXV (Sweat)	022-09093-000	022-09092-000	025-39910-000
		TXV (Flare)	---	---	025-32798-048
*	29	Harness, Solenoid Coil	1456-9771	1456-9771	1456-9771
1	30	Ground Lug	025-21798-000	025-21798-000	025-21798-000
1	31	Strain Relief	1216-243	1216-243	1216-243
1	32	Guard, Coil (1 Req'd)	373-23847-001	373-23790-005	373-23715-007
1	33	Guard, Fan	026-35511-822	026-35511-824	026-35511-824
1	34	Isolator, Compressor (Pkg. of 4)	9435-1081	028-12355-000	028-12355-000
1	35	Plastic Mesh, Coil Guard	028-14733-000	028-15243-000	028-14734-000
*	36	Fastener, Push-in (4 Req'd)	021-18381-000	021-18381-000	021-18381-000
*	37	Diagram, Wiring	125830	125830	125830
1	38	Kit, Motor Mounting (Acorn Nuts)	363-90117-700	363-90117-700	363-90117-700
1	39	Filler, Panel	---	073-23789-001	073-23758-002
*	40	Tank, Compensator	---	---	026-35434-000

NOTE: *Not ShownNew replacement parts shown in **bold** face type at the first printing of parts list dated 3/08.

Major components and suggested stocking items are shown with shaded item number.

< Across from row indicates a change in that row.

--- Not applicable to specified model.

Refer to Tech Guide for proper selection of orifice.

TO ORDER AUTHORIZED FACTORY REPLACEMENT PARTS - Contact your Source1 HVAC Parts Distributor or visit our website at **www.Source1Parts.com** for a Distributor and Dealer listing.